

NuMicro® Family
Based on Arm® Cortex®-M4

MotorKit Nu-KT-MTR_M4BF54K
User Manual
NuMicro® KM1M4BF Series

The information described in this document is the exclusive intellectual property of Nuvoton Technology Corporation Japan (NTCJ) and shall not be reproduced without permission from Nuvoton.

Nuvoton is providing document only for reference purposes of NTCJ Microcontroller based system design.

*Nuvoton assumes no responsibility for errors or omissions.
All data and specifications are subject to change without notice.*

For additional information or question, please contact Nuvoton Technology Corporation Japan.

www.nuvoton.co.jp

Table of Contents

1.	OVERVIEW	4
2.	HARDWARE CONFIGURATION	5
2.1	Top View	5
2.2	Bottom View	6
2.3	Inverter board Connectors	7
2.3.1	Pin Assignment for Inverter board Connectors	7
2.4	Function Jumpers	10
2.4.1	Setting for Function Jumpers	10
2.5	RAM monitor Tool Connector	11
2.5.1	Pin Assignment for RAM monitor Tool Connector	11
2.6	Serial Interface Connector	12
2.6.1	Pin Assignment for Serial Interface Connector	12
2.7	DA converter output pin	12
2.7.1	Pin Assignment for DA converter output pin	12
2.8	Unused Pins connection	13
2.8.1	Pin Assignment for Unused pins	13
2.9	Debug Interface Connector	14
2.9.1	Pin Assignment for Debug Interface Connector	14
2.10	LED	15
2.11	External Power Connector	15
2.12	Reset Switch	15
2.13	Crystal Oscillator	15
3.	NU-KT-MTR_M4BF54K SCHEMATICS	16
3.1	Nu-KT-MTR_M4BF54K	16
3.2	PCB Component Placement	17
4.	REVISION HISTORY	18

List of Figures

Figure 2-1 Top View of Nu-KT-MTR-M4BF54K	5
Figure 2-2 Bottom View of Nu-KT-MTR_M4BF54K	6
Figure 3-1 Nu-KT-MTR_M4BF54K Schematic	16
Figure 3-2 Top Placement.....	17
Figure 3-3 Bottom Placement	17

List of Tables

Table 2-1 Inverter board Connectors	7
Table 2-2 Inverter board Connector and KM1M4BF54K Mapping GPIO List.....	8
Table 2-3 Inverter board Connector and KM1M4BF54K Mapping GPIO List.....	9
Table 2-4 Function Jumpers	10
Table 2-5 Function Jumper setting	10
Table 2-6 RAM monitor Tool Connector	11
Table 2-7 RAM monitor Tool Connector and KM1M4BF54K Mapping GPIO List.....	11
Table 2-8 Serial Interface Connector	12
Table 2-9 Serial Interface Connector and KM1M4BF54K Mapping GPIO List.....	12
Table 2-10 DA converter output pin	12
Table 2-11 DA converter output pin and KM1M4BF54K Mapping GPIO List.....	12
Table 2-12 Unused pins	13
Table 2-13 Unused pins and KM1M4BF54K Mapping GPIO List.....	13
Table 2-14 Debug Interface Connector.....	14
Table 2-15 Debug Interface Connector and KM1M4BF54K Mapping GPIO List	14
Table 2-16 LED	15
Table 2-17 External Power Connector	15
Table 2-18 Reset Switch	15
Table 2-19 Crystal Oscillator.....	15

1. OVERVIEW

Nu-KT-MTR_M4BF54K is an inverter control MCU board equipped with KM1M4BF54K.
By connecting this board to the inverter boards Nu-KE-MTR_LV001 or Nu-KE-MTR_HV001,
it is possible to develop motor control applications using the KM1M4BF54K.

[Spec]

Product name : KM1M4BF series MotorKit MCU board

Board product No. : Nu-KT-MTR_M4BF54K

Supported Inverter board : Nu-KE-MTR-LV001(Low voltage), Nu-KE-MTR-HV001(High voltage)

Target MCU : KM1M4BF54K

[CPU] ARM Cortex-M4

[CPU max. operating frequency] 120 MHz

[Package / Pin count] : TQFP / 64 pins

[ROM] Instruction:264 KB, Data:32 KB

[RAM] Data:16 KB

MCU input clock : Crystal Oscillator 10 MHz

Supported debugger : I-Jet, ULINK2, ULINKplus

2. HARDWARE CONFIGURATION

2.1 Top View




Figure 2-1 Top View of Nu-KT-MTR-M4BF54K

Figure 2-1 shows the main components and connectors at the top side of Nu-KT-MTR_M4BF54K.

The following lists components and connectors from the top view:

- Target chip : KM1M4BF54K (U1)
- Inverter board Connector (CN1, CN2)
- Function Jumper (J1, J2, J3, J4, J5, J6, J7, J8)
- DA converter output Pin (DAOT0)
- Unused pins (P11, PD3, PD5)
- External Power Connector (CN5)
- Debug Interface Connector (CN4)
- RAM monitor Tool Connector (CN3)
- Serial Interface Connector (J9)
- LED (LED1)
- Reset Switch (K1)
- Crystal Oscillator(Y1)

2.2 Bottom View




Figure 2-2 Bottom View of Nu-KT-MTR_M4BF54K

Figure 2-2 shows the main components and connectors at the bottom side of Nu-KT-MTR_M4BF54K.

The following lists components and connectors from the bottom view:

- Inverter board Connector (CN1, CN2)

2.3 Inverter board Connectors

Table 2-1 shows the Inverter board Connectors.

Connector	Description
CN1, CN2	Inverter board Connectors for Motor Control on the Nu-KT-MTR_M4BF54K. This connectors connect to the inverter board connector of Nu-KE-MTR_LV001(CN1, CN2) or Nu-KE-MTR_HV001(CN1, CN2).

Table 2-1 Inverter board Connectors

2.3.1 Pin Assignment for Inverter board Connectors

Inverter board Connectors(CN1,CN2) provide interface to KM1M4BF54K MCU on Nu-KT-MTR_M4BF54K.

The Table 2-2, Table 2-3 shows the KM1M4BF54K assignment to Inverter board Connectors.

Header		Pin Name	KM1M4BF54K	
			Pin No.	Function
CN1	CN1.1	VSS	-	VSS
	CN1.2	CT1_A+	54	P46/ADIN06/VGAP10/CMPIN11
	CN1.3	CT1_A-	53	P50/ADIN08/VGAN1/CMPIN10/CMPREF10
	CN1.4	EMG_1	38	P70/IRQ05/IRQ10
	CN1.5	Z1	32	P76/GPWM21/TM05A
	CN1.6	Y1	33	P75/TM04A/GPWM11
	CN1.7	X1	34	P74/TM03A/GPWM01
	CN1.8	W1	35	P73/TM02A/GPWM20
	CN1.9	V1	36	P72/TM01A/GPWM10
	CN1.10	U1	37	P71/TM00A/GPWM00
	CN1.11	TEMP1	56	P44/ADIN04/VGAP12/CMPIN10/CMPIN11
	CN1.12	CT2_A-	60	PF4/ADIN22/VGAN0/CMPIN00/CMPREF00
	CN1.13	CT2_U	59	P40/ADIN00/VGAP00/CMPIN01
	CN1.14	CT2_V	58	P41/ADIN01/VGAP01
	CN1.15	CT2_W	57	P42/ADIN02/VGAP02
	CN1.16	EMG_2	40	P31/IRQ06/IRQ36/TM10A/TM12A/TRCCLK
	CN1.17	Z2	31	P90/SBO6/SBI6/GPWM51
	CN1.18	Y2	30	P91/SBO6/SBI6/GPWM41
	CN1.19	X2	29	P92/SBT6/GPWM31
	CN1.20	W2	28	P93/SBCS6/GPWM50
	CN1.21	V2	27	P94/GPWM40
	CN1.22	U2	26	P95/GPWM30

	CN1.23	TEMP2	55	P45/ADIN05/VGAP11/CMPIN00/CMPIN01
	CN1.24	DC1_V_CHECK	49	P54/IRQ02/ADIN12
	CN1.25	PFC_AD_CT	51	P52/IRQ00/ADIN10
	CN1.26	PFC_AD_VL	50	P53/IRQ01/ADIN11
	CN1.27	PFC_RST	2	P00/ADST1/SBO4/SBI4/IRQ02
	CN1.28	PFC_ZERO	52	P51/IRQ33/ADIN09
	CN1.29	PFC_FO	11	PE2/IRQ13/NMI
	CN1.30	VDD5V	-	VDD50

Table 2-2 Inverter board Connector and KM1M4BF54K Mapping GPIO List

Header	Pin Name	KM1M4BF54K	
		Pin No.	Function
CN2	CN2.1	-	N.C.
	CN2.2	VSS	VSS
	CN2.3	HALL_U	PD4/SBT1/SBO1/TM06B/TM00B/IRQ02
	CN2.4	HALL_V	PD6/ADST0/SBCS3/SBCS1/TM15A/TM01A/IRQ05/GPWM71
	CN2.5	HALL_W	PD7/SBCS3/TM14A/IRQ35/IRQ31/GPWM70
	CN2.6	-	N.C.
	CN2.7	ENC_A	45 P22/IRQ22/IRQ32/TM04A/TM13A/SBI3/SBO3 /CMPOT00/CMPOT01/TRCD2 64 P11/IRQ01/TM03A/TM12A/GPWM00
	CN2.8	ENC_B	46 P21/IRQ06/IRQ21/TM04B/TM11A/TM14A/ADIN21/CMPREF11/TRCD3 52 P52/IRQ00/ADIN10
	CN2.9	ENC_Z	5 P01/SBT4/ADST2/GPWMST6/IRQ15/IRQ04
	CN2.10	SRV_FR	44 P23/TM02A/TM07A/SBI3/SBO3/GPWMST2/GPWMST5/CMPOT10/CMPOT11/CKMREF/TRCD1
	CN2.11	SRV_STMP	43 P24/TM02B/TM06A/SBT3/GPWMST1/GPWMST4/CMPOT00/CMPOT01/DAOT0/TRCD0
	CN2.12	TP0	1 P02/ADST0/SBO4/SBI4/SBCS1/TM15B/IRQ05
	CN2.13	TP1	2 P00/ADST1/SBO4/SBI4/IRQ02
	CN2.14	TP2	5 P01/SBT4/ADST2/GPWMST6/IRQ15/IRQ04
	CN2.15	TP3	- N.C.
	CN2.16	TM_PWM0	43 P24/TM02B/TM06A/SBT3/GPWMST1/GPWMST4/CMPOT00/CMPOT01/DAOT0/TRCD0
	CN2.17	TM_PWM1	1 P02/ADST0/SBO4/SBI4/SBCS1/TM15B/IRQ05
	CN2.18	TM_PWM2	20 PB3/CKMREF/SBT3/SBT2/TM10A/GPWM60

	CN2.19	LED0	-	N.C.
	CN2.20	LED1	-	N.C.
	CN2.21	SW0	-	N.C.
	CN2.22	SW1	-	N.C.
	CN2.23	SW2	-	N.C.
	CN2.24	SW3	-	N.C.
	CN2.25	-	-	N.C.
	CN2.26	GPIO	44	P23/TM02A/TM07A/SBI3/SBO3/GPWMST2/G PWMST5/CMPOT10/CMPOT11/CKMREF/TR CD1
	CN2.27	PFC_PWM0	19 62	PB4/SBCS0/IRQ12/IRQ03/GPWM70 PF5/IRQ34/TM03B/TM12B/GPWM01
	CN2.28	-	-	N.C.
	CN2.29	VDD5V	-	VDD50
	CN2.30	-	-	N.C.

Table 2-3 Inverter board Connector and KM1M4BF54K Mapping GPIO List

2.4 Function Jumpers

Table 2-4 shows the Function Jumpers.

Connector	Description
J1, J2, J3, J4 J5, J6, J7, J8	A jumpers for selecting functions such as Encoder and unused pins.

Table 2-4 Function Jumpers

2.4.1 Setting for Function Jumpers

Table 2-5 shows the KM1M4BF54K Function Jumpers.








Connector		Description
J1		J1(1-2) : Timer PWM output1 J1(2-3) : Test pin0 (TP0)
J2		J2(1-2) : PFC reset output for HV borad* J2(2-3) : Test pin1 (TP1)
J3		J3(1-2) : Serial port J3(2-3) : Timer PWM output2
J4		J4(1-2) : Timer PWM output0 J4(2-3) : Servo (SRV_STMP)
J5		J5(1-2) : Relay control for HV borad* J5(2-3) : Servo (SRV_FR)
J6		J6(1-2) : Unused pin (P11) J6(2-3) : Encoder (ENC_A)
J7		J7(1-2) : Encoder (ENC_Z) J7(2-3) : Test pin2 (TP2)
J8		J8(1-2) : PFC PWM output for HV board* J8(2-3) : Encoder (ENC_B)

Table 2-5 Function Jumper setting

*HV board is high voltage inverter board (Nu-KE-MTR_HV001).

2.5 RAM monitor Tool Connector

Table 2-6 shows the RAM monitor Tool Connector.

Connector	Description
CN3	RAM monitor Tool Connector for connecting RAM monitor Tool (Power Debugger, Debug Oscilloscope) made by Nuvoton Technology Corporation Japan(NTCJ).

Table 2-6 RAM monitor Tool Connector

2.5.1 Pin Assignment for RAM monitor Tool Connector

The Nu-KT-MTR_M4BF54K provides RAM monitor Tool Connector(CN3).

Table 2-7 shows the pin assignment of RAM monitor Tool Connector.

Header		KM1M4BF54K	
		Pin No.	Function
CN3	CN3.1	-	VSS
	CN3.2	23	PF1/SBT5/TM02B/TM00A
	CN3.3	-	VSS
	CN3.4	24	P96/SBO5/SBI5/GPWMST7/IRQ11/IRQ04
	CN3.5	-	VDD50
	CN3.6	-	VDD50
	CN3.7	-	N.C.
	CN3.8	-	VSS
	CN3.9	25	PF2/SBO5/SBI5/IRQ37/IRQ20/IRQ14
	CN3.10	-	VSS

Table 2-7 RAM monitor Tool Connector and KM1M4BF54K Mapping GPIO List

2.6 Serial Interface Connector

Table 2-8 shows the Serial Interface Connector.

Connector	Description
J9	Connector for serial communication(UART/SPI/I2C).

Table 2-8 Serial Interface Connector

2.6.1 Pin Assignment for Serial Interface Connector

The Nu-KT-MTR_M4BF54K provides Serial Interface Connector(J9).

Table 2-9 shows the pin assignment of Serial Interface Connector.

Header		KM1M4BF54K	
		Pin No.	Function
J9	J9.1	-	VDD50
	J9.2	20	PB3/CKMREF/GBT3/GBT2/TM10A/GPWM60 *J3:Pin1-2 connected
	J9.3	21	PB2/SBO2/SBI2/TM10B/IRQ30
	J9.4	22	PB1/GBT2/SBO2/SBI2/TM11A/TM00B
	J9.5	-	VSS

Table 2-9 Serial Interface Connector and KM1M4BF54K Mapping GPIO List

2.7 DA converter output pin

Table 2-10 shows the DA converter output pin.

Connector	Description
DAOT0	Connector for DA converter output

Table 2-10 DA converter output pin

2.7.1 Pin Assignment for DA converter output pin

The Nu-KT-MTR_M4BF54K provides DA converter output pin(DAOT0).

Table 2-11 shows the DA converter output pin.

Header		KM1M4BF54K	
		Pin No.	Function
DAOT0		43	P24/TM02B/TM06A/GBT3/GPWMST1/GPWMST4/CMPOT00 /CMPOT01/DAOT0/TRCD0 *J4:Pin1-2, Pin2-3 open

Table 2-11 DA converter output pin and KM1M4BF54K Mapping GPIO List

2.8 Unused Pins connection

Table 2-12 shows the unused pins connection.

Header	Description
P11, PD3, PD5	The unused pins of the KM1M4BF54K are connected.

Table 2-12 Unused pins

2.8.1 Pin Assignment for Unused pins

The Nu-KT-MTR_M4BF54K provides connection for unused pins (P11, PD3, PD5).

Table 2-13 shows the KM1M4BF54K unused pins connection.

Header	KM1M4BF54K	
	Pin No.	Function
P11	64	P11/IRQ01/TM03A/TM12A/GPWM00 *J6:Pin1-2 connected
PD3	16	PD3/SBO1/SBI1/TM00A
PD5	14	PD5/GBT1/SBO1/SBI1/IRQ36/IRQ30/IRQ03

Table 2-13 Unused pins and KM1M4BF54K Mapping GPIO List

2.9 Debug Interface Connector

Table 2-14 shows the Debug Interface Connector.

Connector	Description
CN4	Debug interface connector for connecting Debugger(I-Jet or ULINK).

Table 2-14 Debug Interface Connector

2.9.1 Pin Assignment for Debug Interface Connector

The Nu-KT-MTR_M4BF54K provides Debug Interface Connector(CN4).

Table 2-15 shows the pin assignment of Debug Interface Connector.

Header		KM1M4BF54K	
		Pin No.	Function
CN4	CN4.1	-	VDD50
	CN4.2	18	PB5/SWDD/SBO0/SBI0/GPWM61
	CN4.3	-	VSS
	CN4.4	17	PB6/SWDCLK/SBT0/SBO0/SBI0/IRQ05/GPWM71
	CN4.5	-	VSS
	CN4.6	42	P30/IRQ07/TM06B/TM10B/TM12B/SBCS3/GPWMST0/ GPWMST3/CMPOT10/CMPOT11/TRCSWO
	CN4.7	-	N.C.
	CN4.8	-	N.C.
	CN4.9	47	NDMOD
	CN4.10	6	NRST

Table 2-15 Debug Interface Connector and KM1M4BF54K Mapping GPIO List

2.10 LED

Table 2-16 shows LED function.

Component	Description
LED1	The power LED indicates that the Nu-KT-MTR_M4BF54K is powered.

Table 2-16 LED

2.11 External Power Connector

Table 2-17 shows the External Power Connector.

Component	Description
CN5	Apply 5V when operating withNu-KT-MTR-M4BF54K standalone. Note : When Nu-KT-MTR-M4BF54K is connected to the inverter board, 5V power is supplied from the inverter board.

Table 2-17 External Power Connector

2.12 Reset Switch

Table 2-18 shows the Reset Switch.

Component	Description
K1	Reset Switch to reset the target chip.

Table 2-18 Reset Switch

2.13 Crystal Oscillator

Table 2-19 shows the Crystal Oscillator.

Component	Description
Y1	10 MHz. Crystal Oscillator

Table 2-19 Crystal Oscillator

3. NU-KT-MTR_M4BF54K SCHEMATICS

3.1 Nu-KT-MTR_M4BF54K

Figure 3-1 shows the Nu-KT-MTR_M4BF54K schematic.




Figure 3-1 Nu-KT-MTR_M4BF54K Schematic

3.2 PCB Component Placement

Figure 3-2 and Figure 3-3 show the top and bottom placement of Nu-KT-MTR_M4BF54K.




Figure 3-2 Top Placement




Figure 3-3 Bottom Placement

4. REVISION HISTORY

Date	Revision	Description
July 11, 2022	1.00	• Initial version

Important Notice

Nuvoton Products are neither intended nor warranted for usage in systems or equipment, any malfunction or failure of which may cause loss of human life, bodily injury or severe property damage. Such applications are deemed, "Insecure Usage".

Insecure usage includes, but is not limited to: equipment for surgical implementation, atomic energy control instruments, airplane or spaceship instruments, the control or operation of dynamic, brake or safety systems designed for vehicular use, traffic signal instruments, all types of safety devices, and other applications intended to support or sustain life.

All Insecure Usage shall be made at customer's risk, and in the event that third parties lay claims to Nuvoton as a result of customer's Insecure Usage, customer shall indemnify the damages and liabilities thus incurred by Nuvoton.

*Please note that all data and specifications are subject to change without notice.
All the trademarks of products and companies mentioned in this datasheet belong to their respective owners.*