NuMicro® Family

Arm® Cortex®-M23-based Microcontroller

NuMaker-M2003FC

User Manual

Evaluation Board for NuMicro® M2003 Series

The information described in this document is the exclusive intellectual property of Nuvoton Technology Corporation and shall not be reproduced without permission from Nuvoton.

Nuvoton is providing this document only for reference purposes of NuMicro microcontroller and microprocessor based system design. Nuvoton assumes no responsibility for errors or omissions.

All data and specifications are subject to change without notice.

For additional information or questions, please contact: Nuvoton Technology Corporation.

www.nuvoton.com

Table of Contents

1 OVERVIEW 6

2 FEATURES 7

3 HARDWARE CONFIGURATION 8

3.1 Front View 8

3.2 Rear View 9

3.3 Extension Connectors 10

3.3.1 Pin Assignment for Extension Connectors 10

3.3.2 Arduino UNO Compatible Extension Connectors 12

3.4 Power Supply Configuration 14

3.4.1 VIN Power Source 14

3.4.2 5 V Power Sources 14

3.4.3 3.3 V Power Sources 15

3.4.4 1.8 V Power Sources 15

3.4.5 Power Connectors 15

3.4.6 USB Connectors 16

3.4.7 Power Switches 16

3.4.8 Power Supply Models 16

3.5 External Reference Voltage Connector 20

3.6 Ammeter Connector 21

3.7 Push Buttons 22

3.8 LEDs 23

3.9 Nu-Link2-Me 24

3.9.1 VCOM Switches 24

3.9.2 Status LEDs 24

4 QUICK START 25

4.1 Toolchains Supporting 25

4.2 Nuvoton Nu-Link Driver Installation 25

4.3 BSP Firmware Download ..... **Error! Bookmark not defined.**

4.4 Hardware Setup 26

4.5 Find the Example Project 30

4.6 Execute the Project under Toolchains 30

4.6.1 Keil MDK 30

4.6.2 IAR EWARM 34

5 NUMAKER-M2003FC SCHEMATICS 36

5.1 Nu-Link2-Me 36

5.2 NuMaker-M2003FC Schematics 37
5.3 Extension Connectors 38
5.4 PCB Placement 39
6 REVISION HISTORY 40

List of Figures

Figure 1-1 NuMaker-M2003FC Evaluation Board 6
Figure 3-1 Front View of NuMaker-M2003FC 8
Figure 3-2 Rear View of NuMaker-M2003FC 9
Figure 3-3 MG51FC Extension Connectors 10
Figure 3-4 Arduino UNO Compatible Extension Connectors 12
Figure 3-5 External Power Supply Sources on Nu-Link2-Me 16
Figure 3-6 External Power Supply Sources on MG51FC Target Board 17
Figure 3-7 Detach the Nu-Link2-Me from NuMaker-M2003FC 18
Figure 3-8 Wiring between Ammeter Connector and Ammeter 21
Figure 3-9 Project Path of PowerDown_BODdisable 21
Figure 4-1 Nu-Link USB Driver Installation Setup ..... **Error! Bookmark not defined.**
Figure 4-2 Nu-Link USB Driver Installation ..... **Error! Bookmark not defined.**
Figure 4-3 Open VCOM Function 28
Figure 4-4 ICE USB Connector 28
Figure 4-5 Device Manger 29
Figure 4-6 PuTTY Session Setting 29
Figure 4-7 Template Project Folder Path 30
Figure 4-8 Warning Message of “Device not found” 30
Figure 4-9 Project File Migrate to Version 5 Format 31
Figure 4-10 Debugger Setting in Options Window 31
Figure 4-11 Programming Setting in Options Window 32
Figure 4-12 Compile and Download the Project 32
Figure 4-13 Keil MDK Debug Mode 33
Figure 4-14 Debug Message on Serial Port Terminal Windows 33
Figure 4-15 IAR EWARM Window 34
Figure 4-16 Compile and Download the Project 34
Figure 4-17 IAR EWARM Debug Mode 35
Figure 4-18 Debug Message on Serial Port Terminal Windows 35
Figure 5-1 Nu-Link2-Me Circuit 36
Figure 5-2 MG51FC Target Board Circuit 37
Figure 5-3 Extension Connectors Circuit 38
Figure 5-4 Front Placement 39
Figure 5-5 Rear Placement 39

List of Tables

Table 3-1 Extension Connectors 10
Table 3-2 MG51FC Full-pin Extension Connectors and GPIO Function List 11
Table 3-3 Arduino UNO Extension Connectors and M2003FC1AE Mapping GPIO List 13
Table 3-4 Vin Power Source 14
Table 3-5 5 V Power Sources 14
Table 3-6 3.3 V Power Sources 15
Table 3-7 1.8 V Power Sources 15
Table 3-8 Power Connectors 15
Table 3-9 USB Connectors 16
Table 3-10 Power Switches 16
Table 3-11 Supply External Power through Nu-Link2-Me 17
Table 3-12 Supply External Power for MG51FC Target Board 19
Table 3-13 External Reference Voltage Connector 20
Table 3-14 Ammeter Connector 21
Table 3-15 Push Buttons 22
Table 3-16 LEDs 23
Table 3-17 VCOM Function of Nu-Link2-Me 24
Table 3-18 Operation Status LED Patterns 24

1 OVERVIEW

The NuMaker-M2003FC is an evaluation board for Nuvoton NuMicro M2003FC1AE microcontrollers. The NuMaker-M2003FC consists of two parts: an M2003FC target board and an on-board Nu-Link2-Me debugger and programmer. The NuMaker-M2003FC is designed for project evaluation, prototype development and validation with power consumption monitoring function. The NuMaker-M2003FC board is suitable for a wide range of applications such as home appliances, LED lighting controls, motor controls or Industrial automation.

The M2003FC1AE target board is based on NuMicro M2003FC1AE. For the development flexibility, the M2003FC target board provides the extension connectors, the Arduino UNO compatible headers and the capability of adopting multiple power supplies. Furthermore, the Nuvoton-designed ammeter connector can measure the power consumption instantly, which is essential for the prototype evaluation.

In addition, there is an attached on-board debugger and programmer “Nu-Link2-Me”. The Nu-Link2-Me supports on-chip debugging, online and offline ICP programming via SWD interface. The Nu-Link2-Me supports virtual COM (VCOM) port for printing debug messages on PC. Besides, the programming status could be shown on the built-in LEDs. Lastly, the Nu-Link2-Me could be detached from the evaluation board and become a stand-alone mass production programmer.



Figure 1-1 NuMaker-M2003FC Evaluation Board

2 FEATURES

- NuMicro M2003FC1AE used as main microcontroller
- M2003FC1AE full pins extension connectors
- Arduino UNO compatible extension connectors
- Ammeter connector for measuring the microcontroller's power consumption
- Flexible board power supply:
  - External V_{DD} power connector
  - Arduino UNO compatible extension connector Vin
  - USB Power connector on MG51FC target board
  - ICE USB connector on Nu-Link2-Me
- On-board Nu-Link2-Me debugger and programmer:
  - Debug through OCD interface
  - Online/offline programming
  - Virtual COM port function

3 HARDWARE CONFIGURATION

3.1 Front View



Figure 3-1 Front View of NuMaker-M2003FC

Figure 3-1 shows the main components and connectors from the front side of NuMaker-M2003FC. The following lists components and connectors from the front view:

- NuMicro M2003FC1AE used as main microcontroller
- M2003FC1AE extension connectors
- Arduino UNO compatible extension connectors
- Ammeter connector for measuring the microcontroller's power consumption
- Flexible board power supply:
  - External V_{DD} power connector
  - Arduino UNO compatible extension connector Vin
  - USB Power only connector on M2003FC1AE target board
  - ICE USB connector on Nu-Link2-Me
- On-board Nu-Link2-Me debugger and programmer:
  - Debug through SWD interface
  - Online/offline programming
  - Virtual COM port function

3.2 Rear View

Figure 3-2 shows the main components and connectors from the rear side of NuMaker-M2003FC.

The following lists components and connectors from the rear view:

- Nu-Link2-Me
  - MCUVCC Power Switch (ICEJPR1)
  - ICEVCC Power Switch (ICEJPR2)



Figure 3-2 Rear View of NuMaker-M2003FC

3.3 Extension Connectors

Table 3-1 presents the extension connectors.

Connector	Description
JP3 and JP4	Full pins extension connectors on the NuMaker-M2003FC.
NU1, NU2, NU3 and NU4	Arduino UNO compatible pins on the NuMaker-M2003FC.

Table 3-1 Extension Connectors

3.3.1 Pin Assignment for Extension Connectors

The NuMaker-M2003FC provides the M2003FC1AE onboard and extension connectors (JP3 and JP4). Figure 3-3 shows the MG51FC extension connectors.



Figure 3-3 MG51FC Extension Connectors

Header		M2003FC1AE	
		Pin No.	Function
JP3	JP3.1	1	P0.5/PWM0_CH2/IC6/T0/ADC_CH4
	JP3.2	2	P0.6/UART0_TXD/ADC_CH3/
	JP3.3	3	P0.7/UART0_RXD/ADC_CH2/
	JP3.4	4	P2.0/nRESET
	JP3.5	5	P3.0ADC_CH1/OSCIN/PWM0_CH3/SPI0_MOSI/IC3/T1
	JP3.6	6	P1.7/ADC_CH0/
	JP3.7	7	VSS
	JP3.8	8	P1.6/ICE_DAT/UART1_TXD/[I2C0_SDA]
	JP3.9	9	VDD
	JP3.10	10	P1.5/PWM0_CH5/IC7/SPI0_SS
JP4	JP5.1	11	P1.4/PWM0_CH1/I2C0_SDA/PWM0_BRAKE
	JP5.2	12	P1.3/I2C0_SCL/[STADC]
	JP5.3	13	P1.2/PWM0_CH0/IC0/
	JP5.4	14	P1.1/PWM0_CH1/IC1/ADC_CH7/CLKO
	JP5.5	15	P1.0/PWM0_CH2/IC2/SPI0_CLK
	JP5.6	16	P0.0/PWM0_CH3/SPI0_MOSI/IC3/T1
	JP5.7	17	P0.1/PWM0_CH4/IC4/SPI0_MISO
	JP5.8	18	P0.2/ICE_CLK/UART1_RXD/[I2C0_SCL]
	JP5.9	19	P0.3/ADC_CH6/PWM0_CH5/IC5
	JP5.10	20	P0.4/PWM0_CH3/IC3/ADC_CH5/STADC

Table 3-2 MG51FC Full-pin Extension Connectors and GPIO Function List

3.3.2 Arduino UNO Compatible Extension Connectors

Figure 3-4 shows the Arduino UNO compatible extension connectors.



Figure 3-4 Arduino UNO Compatible Extension Connectors

Header		NuMaker-M2003FC		Header		NuMaker-M2003FC	
		Compatible to Arduino UNO	GPIO Pin of M2003FC1AE			Compatible to Arduino UNO	GPIO Pin of M2003FC1AE
NU3	NU3.1	RX	PB3	NU2	NU2.6	SCL	NC
	NU3.2	TX	PB2		NU2.5	SDA	NC
	NU3.3	D2	PB11		NU2.4	A3	NC
	NU3.4	D3	PB0		NU2.3	A2	PB12
	NU3.5	D4	P1.2		NU2.2	A1	PB5
	NU3.6	D5	NC		NU2.1	A0	PB4
	NU3.7	D6	NC	NU1	NU1.8	VIN	-
	NU3.8	D7	NC		NU1.7	VSS	
NU4	NU4.1	D8	NC		NU1.6	VSS	
	NU4.2	D9	NC		NU1.5	5V	
	NU4.3	SS/D10	PC14		NU1.4	3V	
	NU4.4	MOSI	PB8		NU1.3	RST	nRESET
	NU4.5	MISO	PB9		NU1.2	IOREF	VDD
	NU4.6	SCK	PB7		NU1.1	NC	-
	NU4.7	VSS	VSS				
	NU4.8	VREF	VDD				
	NU4.9	SDA	PB15				
	NU4.10	SCL	PB14				

Table 3-3 Arduino UNO Extension Connectors and M2003FC1AE Mapping GPIO List

3.4 Power Supply Configuration

The NuMaker-M2003FC is capable of accommodating multiple power supply options. External power sources include NU1 Vin (7 V to 12 V), V_{DD} (depending on the target chip operating voltage), and PC through USB connector. By using switches and voltage regulator, multiple power domains can be created on the NuMaker-M2003FC.

3.4.1 VIN Power Source

Table 3-4 presents the Vin power source.

Connector	Net Name in Schematic	Description
NU1 pin8	NU1_VIN	Board external power source, with voltage range from 7 V to 12 V. The voltage regulator UP2 converts the NU1 pin8 input voltage to 5 V and supplies it to NU1_5VCC.

Table 3-4 Vin Power Source

3.4.2 5 V Power Sources

Table 3-5 presents the 5 V power sources.

Connector	Net Name in Schematic	Description
ICEJ3	USB_HS_VBUS	ICE USB connector supplies 5 V power from PC to MG51FC target board and Nu-Link2-Me.
J2	USB_VBUS	USB connector on NuMaker-M2003FC supplies 5 V power from PC to MG51FC target board and Nu-Link2-Me.
NU1 pin5	NU1_5VCC	ICEJ3, J2 or NU1 pin8 supplies 5 V power to NU1 pin5. NU1 pin5 supplies 5 V power to target chip or Arduino adapter board.

Table 3-5 5 V Power Sources

3.4.3 3.3 V Power Sources

Table 3-6 presents the 3.3 V power sources.

Voltage Regulator	5 V Source	Description
ICEUP1	USB_HS_VBUS	ICEUP1 converts USB_HS_VBUS to 3.3 V and supplies 3.3 V to MG51FC target board or ICE chip.
UP1	USB_VBUS	UP1 converts USB_VBUS to 3.3 V and supplies 3.3 V to MG51FC target board. **Note:** SW2.2 (NU1 3VCC) should be switched to ON.
UP1	NU1_5VCC	UP1 converts NU1_5VCC to 3.3 V and supplies 3.3 V to MG51FC target board. **Note:** SW2.2 (NU1 3VCC) should be switched to ON.

Table 3-6 3.3 V Power Sources

3.4.4 1.8 V Power Sources

Table 3-7 presents the 1.8 V power source.

Voltage Regular	5V Source	Description
ICEUP2	USB_HS_VBUS	ICEUP2 converts USB_HS_VBUS to 1.8 V and supplies 1.8 V to MG51FC target board or ICE chip.

Table 3-7 1.8 V Power Sources

3.4.5 Power Connectors

Table 3-8 presents the power connectors.

Connector	Description
JP1	V_{DD} connector on the NuMaker-M2003FC.
JP2	V_{SS} connector on the NuMaker-M2003FC.

Table 3-8 Power Connectors

3.4.6 USB Connectors

Table 3-9 presents the USB connectors.

Connector	Description
ICEJ3	ICE USB connector on Nu-Link2-Me for power supply, debugging and programming from PC.
J2	USB FS connector on NuMaker-M2003FC for power supply.

Table 3-9 USB Connectors

3.4.7 Power Switches

Table 3-10 presents the power switches.

Switch	Description
ICEJPR1	Configures the target chip operating voltage at 1.8 V / 3.3 V / 5 V.
ICEJPR2	Configures the ICE chip operating voltage at 1.8 V / 3.3 V.
SW2	Configures the target chip operating voltage at 3.3 V / 5 V.

Table 3-10 Power Switches

3.4.8 Power Supply Models

3.4.8.1 External Power Supply through Nu-Link2-Me to Target Chip

The external power supply source on Nu-Link2-Me is shown in Figure 3-5.



Figure 3-5 External Power Supply Sources on Nu-Link2-Me

To use ICEJ3 as external power supply source with Nu-Link2-Me, please follow the steps below:

1. Solder the resistor on ICEJPR1 (MCUVCC) depending on the target chip operating voltage.
2. Solder the resistor on ICEJPR2 (ICEVCC) depending on the ICE chip operating voltage.
3. Switch the SW2 to OFF.
4. Connect the external power supply to ICEJ3.

Table 3-11 presents all power models when supplying external power through Nu-Link2-Me. The Nu-Link2-Me external power sources are highlighted in yellow.

Model	Target Chip Voltage	ICEJ3	ICEJPR1 (MCUVCC) Selection [1]	ICEJPR2 (ICEVCC) Selection [2]	ICE Chip Voltage	SW2 Selection	J2	Vin	JP1
1	1.8 V	Connect to PC	1.8 V	1.8 V	1.8 V	Off	-	-	1.8 V output
2	3.3 V	Connect to PC	3.3 V (default)	3.3 V (default)	3.3 V	Off	-	-	3.3 V output
3	5 V	Connect to PC	5 V	3.3 V (default)	3.3 V	Off	-	-	5 V output

Note:

1. 0 Ω should be soldered between ICEJPR1's MCUVCC and 1.8 V / 3.3 V / 5 V.
2. 0 Ω should be soldered between ICEJPR2's ICEVCC and 1.8 V / 3.3 V.
3. -: Unused.

Table 3-11 Supply External Power through Nu-Link2-Me

3.4.8.2 External Power Supply through MG51FC Target Board to Target Chip

The external power supply sources on MG51FC target board are shown in Figure 3-6.



Figure 3-6 External Power Supply Sources on MG51FC Target Board

To use Vin or J2 as external power supply source, please follow the steps below:

1. Switch the SW2 depending on the target chip operating voltage.
2. Remove the resistor on ICEJPR1 (MCUVCC).
3. Solder the resistor on ICEJPR2 (ICEVCC) depending on the ICE chip operating voltage.
4. Connect the external power supply to Vin or J2.

To use JP1 as external power supply source, please follow the steps below:

1. Switch the SW2 to OFF.
2. Remove the resistor on ICEJPR1 (MCUVCC).
3. Solder the resistor on ICEJPR2 (ICEVCC) depending on the ICE chip operating voltage.
4. Connect ICEJ3 to PC.
5. Connect the external power supply to JP1.

To use Vin or J2 as external power supply source with Nu-Link2-Me detached from NuMaker-M2003FC , please follow the steps below:

1. Switch the SW2 depending on the target chip operating voltage.
2. Detach the Nu-Link2-Me from NuMaker-M2003FC.
3. Connect the external power supply to Vin or J2.

To use JP1 as external power supply source with Nu-Link2-Me detached from NuMaker-MG51FC, please follow the steps below:

1. Switch the SW2 to OFF.
2. Detach the Nu-Link2-Me from NuMaker-M2003FC.
3. Connect the external power supply to JP1.



Figure 3-7 Detach the Nu-Link2-Me from NuMaker-M2003FC

Table 3-12 presents all power models when supplies external power through MG51FC target board. The MG51FC target board external power sources are highlighted in yellow.

Model	Target Chip Voltage	Vin [1]	J2[1]	ICEJ3	SW2 Selection	JP1[2]	ICEJPR1 (MCUVCC) Selection [3]	ICEJPR2 (ICEVCC) Selection [4]	ICE Chip Voltage [5]
4	3.3 V	7 V ~ 12 V Input	-	-	NU1 3VCC	3.3 V output	Remove resistor	3.3 V	3.3 V
5	3.3 V	-	Connect to PC	-	NU1 3VCC	3.3 V output	Remove resistor	3.3 V	3.3 V
6	5 V	7 V ~ 12 V Input	-	-	NU1 5VCC	5 V output	Remove resistor	3.3 V	3.3 V
7	5 V	-	Connect to PC	-	NU1 5VCC	5 V output	Remove resistor	3.3 V	3.3 V
8	2.5 V ~ 5.5 V	-	-	Connect to PC	OFF	DC Input 2.5 V ~ 5.5 V	Remove resistor	1.8 V / 3.3 V	1.8 V / 3.3 V
9	2.5 V ~ 5.5 V	-	-	Nu-Link2-Me removed	OFF	DC Input 2.5 V ~ 5.5 V	-	-	-

Note:

1. The Vin input voltage will be converted by voltage regulator UP2 to 5 V. Supplying external power to Vin or J2 can provide 5 V to NU1 pin5 (5V) and 3.3 V to NU1 pin4 (3VCC).
2. JP1 external power input only provides voltage to target chip.
3. 0 Ω should be removed from ICEJPR1's MCUVCC and 1.8 V / 3.3 V / 5 V.
4. 0 Ω should be soldered between ICEJPR2's ICEVCC and 1.8 V / 3.3 V.
5. The ICE chip voltage should be close to the target chip voltage.
6. -: Unused

Table 3-12 Supply External Power for MG51FC Target Board

3.5 External Reference Voltage Connector

Table 3-13 External Reference Voltage Connector presents the external reference voltage connector.

Connector	Description
VREF1	Connector for user to connect to the external reference voltage pin of the target chip. User needs to remove the L5 ferrite bead.

Table 3-13 External Reference Voltage Connector

3.6 Ammeter Connector

User can refer to the sample code in NUC230_240 series BSP - SYS_PowerDown_MinCurrent and Figure 3-8 to measure the minimum current in Power-down mode. Figure 3-9 shows the path of the sample code, which has relative settings of entering Power-down mode.

Table 3-14 presents the ammeter connector.

Connector	Description
AMMETER	Connector for user to measure the target chip power consumption easily. User needs to remove the R16 resistor.

Table 3-14 Ammeter Connector



Figure 3-8 Wiring between Ammeter Connector and Ammeter



Figure 3-9 Project Path of PowerDown_MinCurrent

3.7 Push Buttons

Table 3-15 presents the push buttons.

Component	Description
ICESW1	Offline program button to start offline ICP programming the target chip.
SW1	Reset button to reset the target chip.

Table 3-15 Push Buttons

3.8 LEDs

Table 3-16 presents the LEDs.

Component	Description
Power LED	The power LED indicates that the NuMaker-M2003FC is powered.
LED1 LED	The LED is connected to the target chip PB13.
ICES0, ICES1, ICES2 and ICES3	Nu-Link2-Me status LED.

Table 3-16 LEDs

3.9 Nu-Link2-Me

The Nu-Link2-Me is an attached on-board debugger and programmer. The Nu-Link2-Me supports on-chip debugging, online and offline ICP programming through SWD interface. The Nu-Link2-Me also supports virtual COM port (VCOM) for printing debug messages on PC. Besides, the programming status could be shown on the built-in LEDs. Lastly, the Nu-Link2-Me could be detached from the evaluation board and become a stand-alone mass production programmer. For more information about Nu-Link2-Me, please refer to *Nu-Link2-Pro Debugger and Programmer User Manual*.

3.9.1 VCOM Switches

Table 3-17 presents how to set the VCOM function by ICESW2.

ICESW2		
Pin	**Function**	**Description**
1	TXD	**On**: Connect target chip P0.6 (UART0_TXD) to Nu-Link2-Me. **Off**: Disconnect target chip P0.6 (UART0_TXD) to Nu-Link2-Me.
2	RXD	**On**: Connect target chip P0.7 (UART0_RXD) to Nu-Link2-Me. **Off**: Disconnect target chip P0.7 (UART0_RXD) to Nu-Link2-Me.
Note: Pin 3 and 4 is unused.		

Table 3-17 VCOM Function of Nu-Link2-Me

3.9.2 Status LEDs

Table 3-18 presents the status LEDs patterns for different operation on Nu-Link2-Me.

Operation Status	**Status LED**			
	ICES0	**ICES1**	**ICES2**	**ICES3**
Boot	Flash x 3	Flash x 3	Flash x 3	Flash x 3
Idle	On	-	-	-
One Nu-Link2-Me is selected to connect	Flash x 3	Flash x 3	Flash x 3	On
ICE online (Not connected to a target chip)	On	-	Flash x 3	Flash x 3
ICE online (Connected to a target chip)	On	-	-	On
ICE online (Failed to connect to a target chip)	On	Any	Flash	On
During offline programming	-	On	-	Flash
Offline programming completed	On	-	-	-
Offline programming completed (Auto mode)	On	On	-	-
Offline programming failed	On	Flash	-	-
Note: “Online” means Nu-Link2-Me is connected to ICP Programming Tool, IDE or NuTool.				

Table 3-18 Operation Status LED Patterns

4 QUICK START

4.1 Toolchains Supporting

Install the preferred toolchain. Please make sure at least one of the toolchains has been installed.

- KEIL MDK Nuvoton edition M0/M23
- IAR EWARM
- NuEclipse GCC (for Windows)
- NuEclipse GCC (for Linux)

4.2 Nuvoton Nu-Link Driver Installation

Download and install the latest Nuvoton Nu-Link Driver.

- Download and install Nu-Link_Keil_Driver when using Keil MDK.
- Download and install Nu-Link_IAR_Driver when using IAR EWARM.
- Skip this step when using NuEclipse.

Please install the Nu-Link USB Driver as well at the end of the installation. The installation is presented in Figure 4-1 and Figure 4-2.



Figure 4-1 Nu-Link USB Driver Installation Setup



Figure 4-2 Nu-Link USB Driver Installation

4.3 BSP Firmware Download

Download and unzip the Board Support Package (BSP).

4.4 Hardware Setup

1. Open the virtual COM (VCOM) function by changing Nu-Link2-Me VCOM Switch No. 1 and 2 to ON.



Figure 4-3 Open VCOM Function

2. Connect the ICE USB connector shown in Figure 4-4 to the PC USB port through a USB cable.



Figure 4-4 ICE USB Connector

3. Find the “Nuvoton Virtual COM Port” on the Device Manger as Figure 4-5.



Figure 4-5 Device Manger

4. Open a serial port terminal, PuTTY for example, to print out debug message. Set the speed to 115200. Figure 4-6 presents the PuTTY session setting.



Figure 4-6 PuTTY Session Setting

4.5 Find the Example Project

Use the “Template” project as an example. The project can be found under the BSP folder as shown in Figure 4-7.



Figure 4-7 Template Project Folder Path

4.6 Execute the Project under Toolchains

Open and execute the project under the toolchain. The section 4.6.1 and 4.6.2 describe the steps of executing project in Keil MDK and IAR EWARM, respectively.

4.6.1 Keil MDK

This section provides steps to beginners on how to run a project by using Keil MDK.

1. Double-click the “Template.uvproj” to open the project.



Figure 4-8 Warning Message of “Device not found”

Note: If Figure 4-8 warning message jumps out, please migrate to version 5 format as shown in Figure 4-9. The “.uvproj” filename extension will change to “.uvprojx”.



Figure 4-9 Project File Migrate to Version 5 Format

2. Make sure the debugger is “Nuvoton Nu-Link Debugger” as shown in Figure 4-10 and Figure 4-11.



Figure 4-10 Debugger Setting in Options Window

Note: If the dropdown menu in Figure 4-10 does not contain “Nuvoton Nu-Link Debugger” item, please rework section .



Figure 4-11 Programming Setting in Options Window

3. Rebuild all target files. After successfully compiling the project, download code to the Flash memory. Click "**Start/Stop Debug Section**" button to enter debug mode.



Figure 4-12 Compile and Download the Project

4. Figure 4-13 shows the debug mode under Keil MDK. Click "**Run**" and the debug message will be printed out as shown in Figure 4-14. User can debug the project under debug mode by checking source code, assembly language, peripherals' registers, and setting breakpoint, step run, value monitor, etc.



Figure 4-13 Keil MDK Debug Mode



Figure 4-14 Debug Message on Serial Port Terminal Windows

4.6.2 IAR EWARM

This section provides steps to beginners on how to run a project by using IAR EWARM.

1. Double click the “Template.eww” to open the project.
2. Make sure the toolbar contains “Nu-Link” item as shown in Figure 4-15.

Note: If the toolbar does not contain “Nu-Link” item, please rework section .



Figure 4-15 IAR EWARM Window

3. Make a target file as presented in Figure 4-16. After successfully compiling the project, download code to the Flash memory and enter debug mode.



Figure 4-16 Compile and Download the Project

4. Figure 4-17 shows the debug mode under IAR EWARN. Click "**Go**" and the debug message will be printed out as shown in Figure 4-18. User can debug the project under debug mode by checking source code, assembly language, peripherals' registers, and setting breakpoint, step run, value monitor, etc.



Figure 4-17 IAR EWARM Debug Mode



Figure 4-18 Debug Message on Serial Port Terminal Windows

5 NUMAKER-M2003FC SCHEMATICS

5.1 Nu-Link2-Me

Figure 5-1 shows the Nu-Link2-Me circuit.



Figure 5-1 Nu-Link2-Me Circuit

5.2 NuMaker-M2003FC Schematics

Figure 5-2 shows the MG51FC target board circuit.



Figure 5-2 MG51FC Target Board Circuit

5.3 Extension Connectors

Figure 5-3 shows extension connectors of NuMaker-M2003FC.



Figure 5-3 Extension Connectors Circuit

5.4 PCB Placement

Figure 5-4 and Figure 5-5 show the front and rear placement of NuMaker-M2003FC.



Figure 5-4 Front Placement



Figure 5-5 Rear Placement

6 REVISION HISTORY

Date	Revision	Description
2024.5.10	1.00	Initial version.

Important Notice

Nuvoton Products are neither intended nor warranted for usage in systems or equipment, any malfunction or failure of which may cause loss of human life, bodily injury or severe property damage. Such applications are deemed, "Insecure Usage".

Insecure usage includes, but is not limited to: equipment for surgical implementation, atomic energy control instruments, airplane or spaceship instruments, the control or operation of dynamic, brake or safety systems designed for vehicular use, traffic signal instruments, all types of safety devices, and other applications intended to support or sustain life.

All Insecure Usage shall be made at customer's risk, and in the event that third parties lay claims to Nuvoton as a result of customer's Insecure Usage, customer shall indemnify the damages and liabilities thus incurred by Nuvoton.

Please note that all data and specifications are subject to change without notice.
All the trademarks of products and companies mentioned in this datasheet belong to their respective owners.