

## CONSMA005 ASSEMBLY INSTRUCTIONS

- Strip cable to recommended dimensions.
- Slip heat shrink and crimp ring onto stripped cable.
- Insert the stripped cable through the retaining nut, shield sleeve. 3. and spacer.
- Solder the socket to the center conductor.
- Insert the socket into the pin insulator, then screw the main body onto the retaining nut.
- Wrap the braid around the tail of the body and crimp the ring with a 0.213" hex crimp tool (or one labeled for use with RG-58 cable).
- Use heat shrink to cover crimp.
- Use the nut and washer to secure the connector to a case.

- 1. ALL DIMENSIONS ARE IN INCHES [mm].

- 2. DIMENSIONS APPLY AFTER FINISHING. WARNING: THIS DRAWING CONTAINS PROPRIETARY INFORMATION

THAT IS THE SOLE PROPERTY OF LINX TECHNOLOGIES, AND SHALL BE

4. SAFETY BREAK ALL SHARP CORNERS AND EDGES .02 MAXIMUM.

**MERLIN, OR 97532** TREATED AS SUCH. NO DISCLOSURE OR REPRODUCTION OF THIS DOCUMENT IS PERMITTED, IN WHOLE OR IN PART, WITHOUT THE TITLE: EXPRESS WRITTEN PERMISSION OF LINX TECHNOLOGIES OR ITS DESIGNATED AGENTS. SMA FEMALE BULKHEAD MOUNT MATERIAL: TOLERANCES: PROJECTION: CABLE END CRIMP FOR RG58 CABLE .020 [0.50]-.200 [5.00]=±.008 [0.20] .200 [5.00]-1.200 [30.00]=±.016 [0.40] 4.75 [120.0]-12.40 [315.0]=±.040 [1.0] ANGLES: ±1° SIZE DWG. NO. CONSMA005-R58 FINISH: DRAWN: B.MURPHY DT: 29-JUN-12 DT: 29-JUN-12 | SCALE: 2:1 **ENGR: S.HOGAN** DO NOT SCALE DRAWING SHEET 1 OF 1

REV

В

159 ORT LANE