DIN 41612 · Coding systems



Identification	Part number	Drawing Dimensions in mm
Coding system without contact loss with code pin	Code pin	With the aid of the marked indents between the contact rows of the male connector a hole has to be drilled at the desired position (also see drawing). The code pin can then be inserted into the corresponding cavity of the female connector by means of the insertion tool. This coding system is available only for the types D, E, F and interface connectors I.
with code pin	09 06 000 9950	Metal
	Insertion tool	- ARRADAP F
	09 99 000 0103	Mounting example
		Code pin Code pin
		Types D, E
shroud coding		Insert the code key into one of the keyways of the female connector as
	Code key	shown in the drawing. Break out the corresponding area of the male shroud. Connectors coded this way can only be applied in a minimum rack spacing
Type F	09 06 001 9919	of 20.32 mm.
		Type F
		Code key
		Type H Type MH
shroud coding	Code key	Турстинт
Types H, MH 24 + 7	09 06 001 9918	
		Code key
Tables 1		
Tool for breaking out the coding area of the		
male shroud	09 99 000 0242	
		ν-